



Assembly Instruction

ITEM NO.: 9357GY-AC





ARMLESS CHAIR




Legs & hardware are stored at the bottom of seat, please take out the legs and hardware for assembly.

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


Component list

No	Drawing	Qty	Description
A		1	SEAT
B		1	BACK
C		2	BRACKET CONNECTOR
D		4	PLASTIC LEG
E		4	PLASTIC WASHER (ϕ 1.89")
F		1	BIG PILLOW (22"X22")


STEP 1



STEP 2



STEP 3



Care Instruction for Textured fabric Furniture:

In order to maintain the original appearance of your Textured fabric Furniture, please

follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Textured fabric.
- Vacuum or wipe with a soft cloth to remove dust.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.