



Assembly Instruction

ITEM NO.: 9357GY-CR





CORNER SEAT




Legs & hardware are stored at the bottom of seat, please take out the legs and hardware for assembly.

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


Component list

No	Drawing	Qty	Description
A		1	SEAT
B		1	LSF BACK
C		1	RSF BACK
D		4	BRACKET CONNECTOR
E		4	PLASTIC LEG
F		4	PLASTIC WASHER (ϕ 1.89")
G		1	BIG PILLOW (22"*22")
H		1	SMALL PILLOW (20"*20")


STEP 1




STEP 2



STEP 3



STEP 4



Care Instruction for Textured fabric Furniture:

In order to maintain the original appearance of your Textured fabric Furniture, please

follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Textured fabric.
- Vacuum or wipe with a soft cloth to remove dust.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.