
Assembly Instruction BF-1UP-ET

Item No.: Description:

BF-1UP-ET Twin XL Wireless Upholstered Adjustable Bed Base
BF-1UP-CT CK Twin Wireless Upholstered Adjustable Bed Base
BF-1UP-Q Queen Wireless Upholstered Adjustable Bed Base
BF-1UP-EK Eastern King Wireless Upholstered Adjustable Bed Base
BF-1UP-CK California King Wireless Upholstered Adjustable Bed Base

BF-1UP-ET*2 Split Eastern King Wireless Upholstered Adjustable Bed Base (2-Piece)
BF-1UP-CT*2 Split California King Wireless Upholstered Adjustable Bed Base (2-Piece)



1. Part Identification




Legs, Retainer Bar(s), Power Supply and Remote Control are in the boxes, please take out all components for assembly. It is tool-less assembly. No tool needed.


NO	Drawing	Qty	Description
А		1	Wireless Upholstered Adjustable Bed Base
В		6	3 Section Leg
С		1	Adaptor
D		1	Plug
Е		1	1 Retainer Bar for ET/CT/Q
		2	2 Retainer Bars for EK/CK
F		1	Remote Control
G	[3]	2	AAA battery
Н		1	Control Box(Pre-assembled)

2. Assembly Steps


Step#1




Step#2



Step#3




3. How to use Remote Control



4. Convenient "Flat Button" on Control Box

In case of power outrage or malfunction of the remote, press the ""Pair/ Flat" button to bring the bed frame to flat position.






Warning:

To reduce the risk of burns, fire, electric shock, or injury to persons:


- 1. Unplug bed frame from outlet before adding or removing accessories.
- 2. Unplug bed frame from outlet before moving it.
- 3. Do not move or drag the bed frame when plug is attached to the outlet.
- 4. Close supervision is necessary when this bed frame is used by, or near children, pets or persons that may need assistance.
- 5. Use bed frame only for its intended use as described in instructions
- 6. Never operate the bed frame if it has a damaged cord or plug for any reason.
- 7. Keep the cord away from heated surfaces or appliances.
- 8. Never drop or insert any object into any bed opening.
- 9. To disconnect, remove plug from outlet.

5. Remote Pairing and Synchronizing

(1) Remote F1 pairing with Base H1.



(For Split King or Split Cal King only) If using 2 bases, remote F1 controls Base H1 and H2 simultaneously. (Remote F1 already is paired with Base H1)



3 Both remote F1 and F2 control Base H1 and H2. (Remote F1 already is paired with Base H1)

